

# Model 1260 Slimline

## Memory phone

### User's guide



#### Equipment Approval Information

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

#### 1. Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

**Notes**

- This equipment may not be used on coin service provided by the telephone company.

- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

US Number is located on the cabinet bottom.  
REN Number is located on the cabinet bottom.

#### 2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

#### Interference information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Privacy of Communications may not be ensured when using this product. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).

- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How to Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Visit our Website at: [www.uniden.com](http://www.uniden.com)



#### Hearing Aid Compatibility (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility.

#### Licensing

Licensed under US Patent 6,427,009.



WARNING! PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

THE LIGHTNING BOLT AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF DANGEROUS VOLTAGE INSIDE THE PRODUCT.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICE TO QUALIFIED SERVICE PERSONNEL.

THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF DANGEROUS VOLTAGE INSIDE THE PRODUCT.

#### Introduction

**CAUTION:** When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

#### Before You Begin

##### Parts Checklist

Make sure your package includes the following items:




#### Telephone Jack Requirements

To use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.

#### Important Installation Information

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

#### Handset Layout



#### Handset Back




#### Installing and Replacing the Batteries

**IMPORTANT:** You will have approximately 60 seconds to replace the batteries before the memories stored in the handset are lost. Please read the instructions before replacing the batteries and have the batteries ready to be inserted beforehand. As a precaution, you may want to write down any stored information you do not want erased.

Your Caller ID phone uses 3 AA-size alkaline batteries for receiving and storing Caller ID records and for the numbers you use for memory dialing.

- If the telephone line cord is connected, disconnect it from the wall.
- Open the battery compartment door with your finger or thumb.



- Insert 3 AA-size alkaline batteries (not included) as shown on the diagram inside the compartment.
- Replace the battery compartment door.

- Insert 3 AA-size alkaline batteries (not included) as shown on the diagram inside the compartment.
- Replace the battery compartment door.

**IMPORTANT:** If you're not going to use the telephone for more than 30 days, remove the batteries because they can leak and damage the unit.

#### Setting Up the Caller ID Menu

**IMPORTANT:** Do not plug the telephone into the wall jack while setting up the Caller ID menu because an incoming call may invalidate the information not yet saved.

- Place the handset in the cradle on the base.
- Press the menu button. **SET**  $\blacktriangle$  **OR**  $\blacktriangledown$  appears in the display.
- Press either  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) button to scroll among the 7 menu screens, which are:

- SET  $\blacktriangle$  OR  $\blacktriangledown$
- Local Area Code (default ---)
- Regional AC'S-1 (default -----)
- CID LANGUAGE (default English)
- SELECT CONTRAST (default 3)
- T/P DIAL MODE (default tone)
- EXIT SETUP

**NOTE:** You may press dial anytime to exit the Caller ID Set Up menu. If no buttons are pressed within 10 seconds, the phone automatically exits the Caller ID Set Up menu and returns to the NO CALLS summary screen.

#### Local Area Code

The telephone uses the programmed area code to determine the number format to display when a valid Caller ID signal is received. It is also used for the Dialback feature.

- Press the menu button. **SET**  $\blacktriangle$  **OR**  $\blacktriangledown$  appears in the display.
- Press the  $\blacktriangle$  (+) button until **LOCAL AREA CODE: \_\_\_** appears in the display.
- To enter or change the area code, press the menu button. The display shows the area code stored in memory. The left-most digit, or a minus sign (-) flashes, indicating the unit is ready to accept the area code entry.
- Press the  $\blacktriangle$  (+) button and select a number from 0-9 in ascending order. Or press the  $\blacktriangledown$  (-) button to select numbers from 9-0 in descending order.
- Press the menu button to advance to the next digit.
- After the 3rd and last digits entered, press the menu button to store the area code and go to the next setting.

**NOTE:** If you make a mistake, you can simply repeat the previous steps until your area code is set.

#### Regional Area Codes for 10-Digit Dialing

Like the Local Area Code, the telephone uses the programmed area codes to determine the number format to display when a valid Caller ID signal is received. Calls that match any of the programmed regional area codes are displayed as 10 digits. This is helpful in areas that have multiple or overlapping area codes and require 10-digit dialing.

- Press the menu button. **SET**  $\blacktriangle$  **OR**  $\blacktriangledown$  appears in the display.
- Press the  $\blacktriangle$  (+) button until **REGIONAL AC'S-1: -----** shows in the display.
- To enter or change the area code, press the menu button. The display shows the area code stored in memory. The left-most digit, or minus sign (-), flashes, indicating the unit is ready to accept the area code entry.
- Press the  $\blacktriangledown$  (-) button, and select a number from 9-0 for the first digit of the are code.
- When the desired digit is flashing, press the  $\blacktriangle$  (+) button to advance to the next digit.
- Press the menu button again to enter the next three-digit regional area code and repeat steps 4 and 5 until all the REGIONAL AC'S-1 (RAC#1) and REGIONAL AC'S-2 (RAC#1) are entered. A total of 6 sets of Regional Area Codes may be entered.
- Press the menu button to store the setting and return to the REGIONAL AREA CODE display.
- Press dial to exit.

#### CID Language

This setting allows you to display Caller ID display prompt messages in English, French or Spanish.

- Press the menu button. **SET**  $\blacktriangle$  **OR**  $\blacktriangledown$  appears in the display.
- Press the  $\blacktriangle$  (+) button until **CID LANGUAGE** appears in the display.
- Press the menu button to show the current language setting. The default is English.
- Press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) button to change the language.
- Press the menu button to store the language and return to the **CID LANGUAGE** display.

#### Select Contrast

This adjustment allows you to select the contrast of the display.

- Press the menu button until **SET**  $\blacktriangle$  **OR**  $\blacktriangledown$  appears.
- Press the  $\blacktriangle$  (+) button until **SELECT CONTRAST** appears in the display.
- Press the menu button to show the current contrast setting. There are 5 levels of contrast, with the default set to 3.
- To decrease the contrast, press  $\blacktriangledown$  (-). To increase the contrast, press  $\blacktriangle$  (+).
- Press the menu button to store the contrast setting and return to the **SELECT CONTRAST** display.

#### T/P Dial Mode

This adjustment allows you to select Tone (touch-tone) or Pulse (rotary) dialing.

- Press the menu button until **SET**  $\blacktriangle$  **OR**  $\blacktriangledown$  appears.
- Press the  $\blacktriangle$  (+) button until **T/P DIAL MODE** appears in the display.
- Press the menu button to show the current dial mode. The default is set to tone.
- To change the dialing mode, press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) button. The display will alternate between the two dialing modes.
- Press the menu button to store the dialing mode and return to the T/P DIAL MODE display.

#### Exit Setup

To immediately exit the setup mode, select the **EXIT SETUP** menu and press the menu button.

**REMINDER:** The time and date is programmed automatically when the first Caller ID record is successfully received after the unit is reset.

#### Telephone Basics

##### Connecting the Telephone Line


- Plug the long straight line cord into a modular wall telephone jack.
- Place the handset in the cradle.

**NOTE:** The unit is properly installed if you pick up the handset and hear the dial tone. Otherwise, recheck all the installation steps.

##### Wall Mount Installation

Your telephone may also be mounted on a wall plate (not included).

**NOTE:** To prevent the handset from falling out of the cradle while the phone is hanging on the wall, you must reverse the handset hook (located on the base).



- Push the handset hook up and out of the slot on the base with your thumb, rotate the hook 180°, and replace it back in the slot.
- Feed the line cord through the groove and wrap the cord around the track on the bottom of the base.
- Feed the line cord through the groove on the opposite side of the track, and plug the end into the modular telephone jack.
- Slip the mounting holes (on the bottom of the base) over the wall plate posts and firmly slide the unit down into place.

##### Adjusting the Ringer Volume

You may control the ringer volume level with the switch located on the side of the base.

- $\text{=}$  = ringer tone will be loud
- $\text{=}$  = ringer tone will be low
- $\text{=}$  = telephone will not ring

##### Adjusting the Volume

You may control the listening level with the VOLUME switch, which has three levels. It remains at the last level set until you change it.

##### Redialing a Number

If you want to call the last number you dialed again (up to 32 digits), use the redial feature.

- Pick up the handset.
- Press the redial button.
- The last number called is automatically redialed.


##### Using One Touch Redial

If the last call you dialed was busy, you can redial it immediately by just pressing the redial button and without hanging up the handset.

##### Caller ID (CID)

**IMPORTANT:** In order to use this unit's Caller ID features, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service. To know who is calling while you are on the phone, you must subscribe to Call Waiting Caller ID Service.

This unit receives and displays information transmitted by your local phone company. This information can include the phone number, date, and time; or the name, phone number, date, and time.



##### Call Waiting Caller ID

Provided you subscribe to Call Waiting Caller ID service form your phone company; if you receive an incoming call and you are using Uniden's multi handset system, a beep indicates the presence of a Call Waiting call on the line. The Call Waiting Caller ID information will be displayed and stored in the history of all handsets in the system.

If you hear the call waiting beep in the handset receiver, press the **flash** button to put the current call on hold and answer the incoming call. Press **flash** again to return to the original call.

##### Receiving CID Records

When you receive a call, the Caller ID information is transmitted between the first and second ring. The Caller ID information appears on the display while the phone rings, giving you a chance to monitor the information and decide whether or not to answer the call.

##### Storing CID Records (In CID Memory)

If you are not at home or cannot answer, your telephone's Caller ID memory stores the data for the 50 most recent calls you received so you can see who called while you were unavailable. When the 51st call is received, the oldest Caller ID record (1st call) is automatically deleted.

You may review the stored information at any time. Calls received since your last review show as NEW in the display. Calls that have not been previously reviewed but were received from the same number more than once show as REPT in the display.

##### Reviewing CID Records

As calls are received and stored, the display is updated to let you know how many calls have been received. To scroll CID records:

- Press either the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) down button to view the newest call record.
- Press the  $\blacktriangledown$  (-) button to scroll through the call records from the most recent to the oldest.
- Press the  $\blacktriangle$  (+) button to scroll through the call records from the oldest to the newest.
- When all of the messages have been viewed, **START/END** appears in the display.

##### Deleting CID Records

- To delete the record showing in the display, press the **delete** button once.
- To delete all records while reviewing, press and hold the **delete** button until **ERASE ALL?** shows in the display, then press the **delete** button again to confirm.

##### Dialing Back

When reviewing Caller ID records, you may dialback the phone numbers shown on the display by pressing the dial button.

**NOTE:** Depending on (a) how the incoming caller's phone number is formatted when it is received, and (b) whether or not you previously pre-programmed your local area code into the set up menu, you may need to adjust the format of the incoming caller's stored phone number before making the call, press the dial button to adjust the number, and try again.

##### If you programmed your local area code in the setup menu

- Use the  $\blacktriangle$  (+) and  $\blacktriangledown$  (-) buttons to scroll to the number you want to dial.
  - If you see a number with 7 digits (i.e. 555-1234), then the call was received from within your area code. However, this does not guarantee the call is a local call.
  - If you see a number with 11 digits (i.e. 1-234-555-1234), then the call received was not from your area code.
- Press the **dial** button and the display shows **PICKUP** or **ADJUST**. A 10 second timer also starts in the upper right side of the display, letting you know the time remaining until the unit returns to the Summary Screen. If you adjust the number to be dialed, the timer automatically resets itself.
- To adjust the phone number, press the dial button. For instance, a 7-digit local number sometimes cannot be dialed because it requires a 10-digit, or 11-digit format. Press the dial button repeatedly to scroll through the 7, 10, and 11-digit numbers.
 

7-digits:	7-digit telephone number (i.e. 555-5555)10-digits: 3-digit area code + 7-digit telephone number (i.e. 425-555-5555)
11-digits:	long distance code 1 + 3-digit area code + 7-digit telephone number (i.e. 1-425-555-5555)

To dial the displayed number, pick up the handset before the timer reaches 0. **NOW DIALING** shows in the display and the number is dialed.

**If you did not program your local area code in the setup menu**

- Use the  $\blacktriangle$  (+) and  $\blacktriangledown$  (-) buttons to display the number you want to dial.
- When you hear the access tone, press the **mem** button and then press 7.
- At the next access tone, press the **mem** button and then 8.
- TIP: Wait for the access tones before pressing the next mem button, or your call may not go through.

**Using Flash**

This feature is used to activate customer calling services available through your local phone company, such as Call Waiting. These services generally require an extra monthly fee. If you subscribe to any of these services, please refer to the phone company's instructions on how to use flash.

**To answer an incoming call while having a conversation:**

- After you hear the Call Waiting tone, press and release the **flash** button. The first call is placed on hold while the second call can be answered.

**To return to your first call and put the second call on hold:**

- Press and release **flash** again. The first call can continue while the second call is put on hold.

##### Memory

Before you store a telephone number in memory, make sure the dialing mode is correctly set for the type of service you have. The default dialing mode is tone (touch-tone), so if you have pulse (rotary) service, you must first change the dialing mode. See "T/P Dial Mode."

##### Storing Frequently Called Numbers

- Pick up the handset.
- Press the store button.
- Push the desired memory location button (0-9).
- Press the store button.
- Use the handset number keys to enter the telephone number (up to 16-digits) and press the store button.
- Hang up the handset.

**NOTE:** If you make a mistake, use the delete button to delete wrong digits.

##### Changing a Stored Number

Repeat the storage sequence above. The new number replaces the old number at the memory location.

##### Erasing a Stored Number

- Pick up the handset.
- Press the **mem** button.
- Press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) buttons for the desired memory location to be erased.
- Press and hold **delete** for three seconds until the number in the display is erased.
- Hang up the handset.

**NOTE:** If you want to erase more than one location, use the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) arrow buttons to scroll to each memory location you want to erase.

##### Dialing Frequently Called Numbers

- Pick up the handset and press the **mem** button.
- Press 0-9 for the memory location. The number dials automatically.
  - OR
- Pick up the handset and press the dial button.
- Press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) buttons for the desired memory location.
- Press the **dial** button to dial the number.
  - OR

- Press **dial** button while the handset is still in the cradle.
- Press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) buttons for the desired memory location, lift the handset and the number dials automatically.

##### Reviewing Numbers Stored in Memory

- Press the **store** button.
- Press 0-9 for the memory location. The number shows on the display.

##### Copy Caller ID Memory to User Memory

- Pickup the handset.
- Press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) buttons to display the number you want to copy.
- Press the **store** button.
- Press 0-9 for the memory location. The display flashes if the memory location is occupied.
- Press the **store** button twice to replace the new information with the old, or press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) buttons to select an empty location. The number is automatically stored.
- Press the hook switch to exit.

##### Copy Redial Memory to User Memory

- Pickup the handset.
- Press **store**.
- Press 0-9 for the memory location. Press the  $\blacktriangle$  (+) or  $\blacktriangledown$  (-) buttons to select a different location. The display flashes if the memory location is occupied.
- Press the **store** button again to confirm.
- Press the **redial** button, and then press the **store** button again.
- Press the **flash** button or the hook switch to exit.

##### Storing a Pause in Memory

The redial button has dual functionality. It becomes a pause button if the store button is pressed first. It is valid only when storing a number into memory. Use the redial button to insert a pause when a delay is needed in an automatic dialing sequence. For example, when you must dial a 9 to get an outside line, or when you enter codes to access your long distance company. You may need to adjust the length of the pause. It can be adjusted from 1 to 9 seconds. The default setting is 4 seconds.

- Pickup the handset.
- Press the **store** button.
- Press the **redial** button.